

Modem
Charging
Cradle

Quick
Connect
Guide



1



Place your Palm device into the cradle snugly to communicate or recharge the battery.

- Parts List:
1-Modem Charging Cradle
1-Quad-band Antenna
1-Power Adapter
4-Power Adapter Connector Tips
1-SIM card with activated data plan
1-Quick Connect Guide (this document)



4

Plug the barrel end of the power adapter into the power connector on the rear of the cradle.

Power Supply
(with changeable tips)



5

Select a power tip to fit your power outlet's connector. To add a power tip to the power adapter, press the small button in the center and slide the tip into place. Then insert the power adapter into your power source.

2

Connect the antenna to the antenna stub on the back of the cradle.



Angle the antenna as required for best reception.



6

Prepare the Modem Charging Cradle

You must use the Network Manager to prepare the Modem Charging Cradle to communicate with your network.

Instructions on using Network Manager are contained in the User Manual which can be downloaded from the website at: www.Janam.com.

3

Use the stylus to press the ejector pin to the right of the SIM card receptacle tray on the rear of the cradle. After the tray opens, insert the SIM Card into the tray so that the gold contacts of the SIM are visible and the notched corner of the card matches the notched corner of the tray and then press the receptacle back into the cradle.



SIM Card w/gold contacts up

Ejector Pin



Power tip assortment allows the adjustable power adapter to connect to all power sources.

Regulatory Information

This device is designed to be compliant with rules and regulations in locations it is sold and will be labeled as required.

CAUTION

The Cradlepoint Regulatory Engineering Department must approve changes or modifications not covered in this user guide in writing. Changes or modifications made without written approval may void the user authority to operate this equipment.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation Cradlepoint, Inc. is not responsible for radio/TV interference caused by using unauthorized cables or by making unauthorized changes to this equipment.

EUROPEAN UNION

This device complies with all requirements of the following specifications:
EN301 489-1 V1.4.1, EN301 489-7 V1.2.1, EN301 511 V9.0.2, 3GPP TS51.010-1 v6.2.1, EN60950-1:2001.